



Numero	Código	Descrição
1	0751031901	PROTETOR DE BORRACHA - SGT 0318/0319
2	0751031902	CARCACA - SGT 0318/0319
3	0751031903	O-RING - SGT 0318/0319
4	0751031904	HASTE DA VALVULA - SGT 0318/0319
5	0751031905	CONECTOR DO DISCO - SGT 0318/0319
6	0751031906	O-RING (PC 06) - SGT 0318/0319
7	0751031907	VALVULA SELETORA - SGT 0318/0319
8	0751031908	ANEL TRAVA - SGT 0318/0319
9	0751031909	DEFLETOR DE ESCAPE - SGT 0318/0319 S/A
10	0751031910	SILENCIADOR - SGT 0318/0319
11	0751031911	SEDE DE VALVULA - SGT 0318/0319
12	0751031912	VALVULA - SGT 0318/0319
13	0751031913	MOLA - SGT 0318/0319
14	0751031914	ENTRADA DE AR - SGT 0318/0319
15-1	0752013641	DISCO VELCRADO 6" S/ FUROS
16	0751031916	GATILHO - SGT 0318/0319
17	0751031917	PINO DO GATILHO - SGT 0318/0319
18	0751031918	ANEL TRAVA (PC 18) - SGT 0318/0319

Numero	Código	Descrição
19	0751031919	ROLAMENTO 6000ZZ - SGT 0318/0319
20	0751031920	PLACA TRASEIRA - SGT 0318/0319
21	0751031921	O-RING DO CILINDRO - SGT 0318/0319
22	0751031922	CILINDRO - SGT 0318/0319
23	0751031923	PINO GUIA DO CILINDRO - SGT 0318/0319
24	0751031924	PALHETA - SGT 0318/0319
25	0751031925	ROTOR - SGT 0318/0319
26	0751031926	PLACA DIANTEIRA - SGT 0318/0319
27	0751031927	O-RING (PC 27) - SGT 0318/0319
28	0751031928	EIXO EXCENTRICO - SGT 0319
29	0751031929	CHAVETA - SGT 0318/0319
30	0751031930	ANEL ROSCADO - SGT 0318/0319
31	0751031931	ROLAMENTO 6001ZZ - SGT 0318/0319
32	0751031932	GUARDA PO DO ROLAMENTO - SGT 0318/0319
33	0751031933	ARRUELA ESPACADORA - SGT 0318/0319
34	0751031934	ARRUELA ESPACADORA (PC 34) - SGT 0318/0319
36	0751031936	ANEL TRAVA (PC 36) - SGT 0318/0319
37	0751031942	BASE PROTETOR DO DISCO - SGT 0319 S/A